



























ASSEMBLY INSTRUCTIONS

DINING TABLE MODEL#: UCD7017




A  X 10	B  X 16	C  X 1	D  X 1	E  730mm X 2
F  X 2	G  X 8	H  X 8	I  X 1	J  X 4
K  X 1	L  320mm X 6	M  X 4		






1**2****3**

4




5




6**7**


8



9



10



11

