


















No	Part	Qty
1	Headboard	1
2	Right Bedside	1
3	Left Bedside	1
4	Foot Board	1
5	Bed Support	1
6	Bed board	3

HARDWARE FOR BED			
No	Part		Qty
A	 	M6x18	16
B		Cover Cap $\phi 50$	8
C		Threaded Bolt M8x70	4
D		Spanner M8/13mm	1
E		Nut M8	8
F		Maxiluna Washer $\phi 40 \times 15$	8
G		Threaded Bolt M8x90	4
H		Spanner (5mm)	1
I		Gasket M8	4
J		Angle Iron	2
K		Junction box	1

HARDWARE FOR BEDSUPPORT			
No	Part		Qty
L		Nut M6	8
M		Gasket M6	16
N	 	Screw M6x45	8

- Please check contents and read instructions before commencing assembly.
- Please use a soft mat to avoid damaging during assembly
- Assemble this article following the enclosed instructions carefully.



**STEP1**

⑤

		M6x45
		Nx8
	Nut M6	
	Lx8	
	M6	
	Mx16	

**STEP2**

② ③

		M6x18
		Ax8

**STEP3**

④ ③ ⑤


	M8x70
	Cx4
	φ40x15
	Fx4
	Nut M8
	Ex4
	Cover Cap φ50
	Bx4
	M8/13mm
	Dx1



**STEP4**

①


	Gasket M8
	Ix4
	M8x90
	Gx4
	Nut M8
	Ex4
	φ40x15
	Fx4
	Cover Cap φ50
	Bx4
	M8/13mm
	Dx1
	Hx1

STEP5




 Angle Iron Jx2	 M6x18 Ax8
---	---


STEP6



STEP7



Attension: The adaptor current needs to be 12W.

 Junction box Kx1
---